A2ZWORLD
Tuya Smart

Instruction Manual
TV01 Zigbee
Thermostat Radiator Valve

English

works with alexa · works with Google Assistant

MMT2103

• Bitte scannen Sie den QR–Code, um das deutsche Handbuch, das Installationsvideo und die Funktionsanforderung zu erhalten
• Escanee el código QR para obtener el manual en español, el video de instalación y la introducción de la función
• Veuillez scanner le code QR pour obtenir le manuel en français, la vidéo d'installation et l'introduction de la fonction
• Отсканируйте QR-код, чтобы получить руководство на русском языке, видео по установке и описание функций
• Scansionare il codice QR per ottenere il manuale in italiano, il video di installazione e la guida alle funzionalità. Video di installazione e funzionalità
• Leia o código QR para obter o manual em português, o vídeo de instalação e a introdução das funções
• Zeskanuj kod QR, aby uzyskać instrukcję, filmy instalacyjne i funkcje

• QR コードをスキャンして、日本語のマニュアル、インストールビデオと機能紹介をご入手ください
• QR 코드를 스캔하면 한국어 설명서, 설치 동영상, 기능 가이드 를 받으 수 있습니다



• امسح الكود
• 请扫描二维码获取说明书手册，安装视频和功能介绍

1.Information about this manual

Please read this manual completely and carefully before starting to use the device. The manual contains important information about the intended use of the device. Especially observe the safety notes. Keep the manual for later consultation. If you hand over the device to other persons for use, please also hand over this manual for reference.

2. Product Description

The device receives a valve to intelligently control the flow of heat to the radiator. With the Thermostat Radiator Valve TV01 you can conveniently adjust the room temperature between 5–30°C, and save more than 15% of energy. The device is part of the Tuya smart home system and works with the ZigBee 3.0 protocol. All devices on the system can be configured comfortably and individually with the Tuya smartphone app.The temperature can be controlled individually, room by room.The radiator thermostat fits to all common radiator alves and is easy to mount–without having to drain any water or interrupt the heating system. The integrated boost function enables the room to be heated up quickly for a brief period. Before leaving home, the valve can be set. There will be a pleasant room temperature right away because of the radiated heat.

3. Device Overview

4. Start–up

4.1 Before we get started

• 2×AA batteries are required for TV01 to work, please get prepared.
• A smart gateway/hub is required for the TV01 to work.
• Temperature is shown in degrees Celsius.

4.2 Inserting (Optional) the batteries

• Pull off the battery compartment cover on the underside of the device.
• When 1 set (2Nr)Nitrogen(AA) batteries in the battery compartment making sure they are the right way round.
• Reattach the battery compartment cover and latch it into place.



The service life of new alkaline batteries is approximately 1.5 years. A battery symbol (🪫) on the display indicates that the batteries need to be replaced. After removing the empty batteries, wait, approx. 1 minute before inserting the new ones. This device does not support operation with rechargeable batteries.

4.3 Set date and time

If batteries are inserted or replaced, the date and time is automatically requested after a brief display of the firmware version number.
• Set the year, month, day and time with the "+" button, and confirm with Menu button. You can press the Boost button to return to the previous menu or to set the next setting of date and time.
• The display of "Ad" with the rotating "⏱" shows that the motor is still adapting.
• When Valve Plane A is aligned with Plane B.
• Install the round tube into the device.
• Install the device.

If the adapting runs is initiated before installation, press pair button and the motor travels back to the " InS " position. If an error message (F1,F2,F3) is displayed, press the Pair/Boost button and the motor similarly travels back to the " InS " position.

5. Installation of the radiator thermostat

The radiator thermostat is easy to install and can be done without draining heating water or intervening in the heating system. No special tools are required, only the heating has to be switched off.
The ring nut attached to the radiator thermostat can be used universally and without accessories for all valves with a thread size of M30 x 1.5 from the most popular manufacturers such as:

Danfoss Heimeier MNG Junkers Landis&Gyr (Duodyr)
Honeywell–Braukmann Oventrop Schlösser Comap
Valf Sanayii Mertik Maxitrol Watts Wingevorth (Winoflex)
Idmar54 R.B.M Tiemme Jaga Siemens

By means of the adapters in the delivery, the device can be installed on radiator valves of type Danfoss RA, Danfoss RAV and Danfoss RAVL.

5.1 Unscrew your existing radiator thermostat

No worries, water will not leak from the valve.

5.2 M30 x 1.5mm

Screw the TV01 smart radiator thermostat directly onto the radiator if the connector type is M30 x 1.5 (picture shown as below). You can adjust the angle to make the led facing the viewer properly.
—Rotate the adapter dial to the maximum value, the max value may be 6 or 8.
—Check ⚙ is active.
—Install the device.



5.3 Danfoss RAVL Valve

• Check the ⚙ is active.
• The valve bodied have elongated notches around their circumference, which ensure that the adapter is properly seated when it snaps on snap on the adapter completely,so that the pins inside the adapter are lined up with the notches on the valve.
• Install the adapter.Plane A is aligned with Plane B.
• Install the round tube into the device.
• Install the device.



5.4 Danfoss RAV Valve

• Rotate the thermostat dial to the maximum value, the max value may be 6 or 8.
• Check the ⚙ is active.
• The valve bodied have elongated notches around their circumference, which ensure that the adapter is properly seated when it snaps on snap on the adapter completely,so that the pins inside the adapter are lined up with the notches on the valve.
• Install the adapter.Plane A is aligned with plane B.
• Union nut.
• Install the device.



6. Interface display

When you see the LED is showing information as below, the radiator thermostat is ready for configuration. If not, please uninstall and re-install the batteries and reset the device.



7. Preparation for use

7.1 Download MOES App

—Download the Tuya Smart/Smart Life App for your mobile device from App Store or Google Play.

MOES App is upgraded as much more compatibility than Tuya Smart/Smart Life App, functional wait for scene controlled by Siri, widget and scene recommendations, as well as the fully new customized layout.
(Note: Tuya Smart/Smart Life App still works, but MOES App is highly recommended)

7.2 Registration or Log in

Enter the Tuya Smart/Smart Life interface ; tap "Register" to create an account by entering your phone number to get verification code and " Set password". Choose "Log in" to activate the main modes.

Note:
The switch only supports 2.4G network,If you have connected 5G network,please disconnect 5G network firstly and connect 2.4G network.

7.3 Add Thermostat Radiator Valve

—Open Tuya Smart or Moes App, use your phone number or email address to register and login. Tap + on the top right, choose Gateway Control–Wireless Gateway (ZigBee) and simply follow the inbuilt setup wizard for device installation and configuration.
—After the ZigBee gateway has been added successfully, you can add the sub–device on the gateway hub interface.
—Long press Pair button on the radiator thermostat for 5 seconds until the Zigbee signal icon flashed, which means the device has entered the pairing mode.
—The blue LED indicator at gateway hub flashed,indicates pairing process.
—When the radiator thermostat is successfully added, the blue LED indicator will extinguish within 1 second, the device Zigbee signal is always on.

8. Product features

8.1 Auto Mode

In automatic mode, the temperature is controlled in accordance with the weekly program you have programmed. Manual changes are activated until the next point at which the profile changes. Afterwards, the defined heating profile will be activated again. To activate the automatic mode, please proceed as follows:
—Press the pair button to select [⏲] icon.
—Default temperature 17℃ and 21℃.
—Temperature range: 5–30 ℃, step: 0.5 ℃.
—**App operation:** Click the manual mode icon in the App control panel.

8.2 Manual Mode

In manual mode, the temperature is controlled in accordance with the current temperature set via "+/–" button. The temperature remains activated until the next adjustment. To activate the manual mode, please proceed as follows:
Default temperature 5℃.
Temperature range: 5–30℃, step: 0.5 ℃.
App operation: Click the manual mode icon in the App control panel.

8.3 Holiday Mode

When you go out or go to a party, you will use the holiday mode. The holiday mode will automatically start at the set time during your and run the holiday temperature.
—After the ZigBee mode is not activated, and you want to view the holiday mode function, please press the pair button to select [⏲] icon, then press [⏲] will flash for 5 seconds and then it will automatically return to the automode icon. Or you can press any button after 5 seconds, press the pair button to cancel.
App operation: Click the Mode icon in the App control panel, and switch to any other mode to cancel holiday mode.

8.4 Open Window Detection

The device automatically stop heating when it detects a sudden temperature drop(5℃ in 5 minutes as default). This is usually caused by an opened window or door and the open window icon will display [⏲] on the screen. The device will resume to its previous status after detection if no actions is implemented. Or you cammanually resume the device by pressing any mode button.
App operation: Click the open window icon in APP to cancel the window opening function.
The open window detection only operates in automatic mode and manual mode.

RECYCLING INFORMATION

All products marked with the symbol for separate collection of waste electrical and electronic equipment (WEEE Directive 2012/19 / EU) must not be disposed of with unsorted waste. You must return all the product at the end of its useful life to the environment, the equipment for disposal of at designated collection points for electrical and electronic equipment designated by the government or authorities. Correct disposal and recycling will help prevent potential negative consequences for the environment and human health. To find out where these collection points are and how they work, contact the installer or your local authority.

WARRANTY CARD

Product Information

Product Name:_____
Product Type:_____
Purchase date:_____
Warranty Period:_____
Dealer Information:_____
Customer's Name:_____
Customer Phone:_____
Customer Address:_____

Thank you for your support and purchase at we Moes, we are always here for your complete satisfaction, just feel free to share your great shopping experience with us.

If you have any other need,please do not hesitate to contact us first, we will try to meet your demand.

FOLLOW US

@moes.smart · MOES.Official · @moes_smart · @moes.smart · @moes_smart · www.moes.net

EVATEST CONSULTING LTD
Unit 2 Cardiff Business Park, Hoy Road Business Centre, Taffs Well, Cardiff, Wales, CF15 7RA
Tel: +44(0)2920 812 812
Email: contact@evatestester.com

EVATEST GmbH
Lauterstraße 23, ESSEN 45326
Email: info@ems-ab.de
Tel: +4917452268066
Made in China

Manufacturer:
WENZHOU NOVA NEW ENERGY CO.,LTD
Address: Power Science and Technology Innovation Center, NO.238, Wei 5 th West Rongyao Road, Economic Zone, Yueqing, Zhejiang, China
Tel: +86–577-87196615
After-sale Service: service@moesshouse.com

Maintenance Records

Failure date	Cause Of Issue	Fault Content	Principal

8.5 Offset Temperature

As the temperature is measured on the radiator thermostat, the temperature distribution can vary throughout a room. To adjust this, a temperature offset of –5 °C to +5 °C can be set in 0.5 °C increments (e.g. 20 °C is set but the room presents with only 18 °C, an offset of –2°C needs to be set. In app settings, the offset temperature is 0 degrees by default. To adjust the offset temperature, please proceed as follows:
• Long press the menu button for 5 seconds, it will enter the setting interface.
• Select "Offset" option via "+/–" button, and press menu button to enter the offset temperature interface.
• Set the desired offset temperature using "+/–" button and confirm with the menu button.
App operation: Click the offset icon in the App settings screen.

8.6 Eco and Comfortable Temperature

The comfort and Eco temperature button makes switching between comfort and Eco temperature simple and user friendly. These have been set at the factory at 21.0°C (comfort temperature) and 17.0°C (Eco temperature). They can be adjusted as desired.
• Press menu button to select comfortable temperature(☼) or Eco temperature(🌙).
App operation: Click the Comfortable/Eco temperature icon in the App control panel to select the corresponding temperature mode.
Even in auto mode, the temperature can be changed at any time using the rotary knob. It will then remain the same until the next point at which the program changes.

8.7 Child Lock

Operation of the device can be locked to avoid settings being changed unintended (e.g. through inquisitive touch). To activate/deactivate the child lock, please proceed as follows:
• Long press the mode button for 5 seconds, it will show LOC symbol on the screen and the device button cannot be used.
• Long press the mode button for 5 seconds to unlock child lock.
App operation: Click the child lock icon in the App settings screen.

8.8 Anti–Freezing Mode

The device operation
• In the manual mode, when the temperature is manually adjusted to less than 5°C, the device will display "AST", and the anti–freezing function will be started to ensure that the indoor temperature is "5" degrees.
• Press any button to cancel anti–freezing function and return to automatic mode.
App operation
• Click the anti–freezing icon (❄) in the App control panel to cancel the boost function. Press the menu button for 5 seconds, enter Setting/Date Week programming stage/Open window detection temp/ECO temp/Offset/Holiday setting.
App operation: Click the settings icon (⚙) in the App control panel.

9. Setting

9.1 Date

To set the date and time, please proceed as follows:
• Long press the menu button for 5 seconds, it will enter the setting interface.
• Select "Date/Time" option via "+/–" button, and press menu button to enter the Date/Time setting interface.
• Select the desired year/month/day/hour/minute the menu button. To confirm, the time flashes using the "+/–" button and confirm with three times.
• Use the boost button to return.
Note: When the device is successfully paired with the phone, the clock time is synchronized with the phone time.

9.2 Week Programming Stage

In this menu item, you can create a heating profile with heating and cooling phases according to your personal needs. You can set up to ten stages of temperature every day. The factory default is five stages.
• Press the menu button for 5 seconds to open the programming menu.
• Select "Prg" using the "+/–" button and confirm with the menu button.
• In the menu item "SAy" , use the "+/–" button to select single days of the week, all weekdays, the weekend or the entire week for your heating profile and confirm with the menu button.
• Confirm the start time 00:00 pm with the menu button.
• Select the desired temperature using the "+/–" button and confirm with the menu button.
• The next time is shown in the display. You can adjust the time via the "+/–" button.
• Select the desired temperature for the next time period using the "+/–" button and confirm with the menu button.
• Temperature range: 5–30℃, step: 0.5 ℃.
• Repeat this procedure until temperatures are stored for the entire period between 0:00 and 24:00 h. To confirm, the temperature flashes three times.

APP operation: Click the comfortable temperature icon (☼) in the App settings screen.

9.5 ECO Temperature

Press the menu button for 5 seconds to open the configuration menu.
• Select "ECO" using the "+/–" button and confirm with the menu button.
• Select the desired temperature using the "+/–" button and confirm with the menu button.
• The next time is shown in the display. You can adjust the time via the "+/–" button.
• Select the desired temperature for the next time period using the "+/–" button and confirm with the menu button.
• Temperature range: 5–30℃, step: 0.5 ℃.
• Repeat this procedure until temperatures are stored for the entire period between 0:00 and 24:00 h. To confirm, the temperature flashes three times.
• Use the boost button to return.
APP–Berlin: Klicken Sie auf das ECO – Temperatursymbol (🌙) in der Einstellungsbildschirm.

9.6 Offset

Press the menu button for 5 seconds to open the configuration menu.
• Select offset icon (**Offset**) via the "+/–" button in the menu.
• Confirm with the menu button.
• Select the desired temperature using the "+/–" button and confirm with the menu button. The temperature flashes three times.
• Temperature range: -5–5℃, step:0.1℃.
• Use the boost button to return.
APP operation: Click the Offset temperature icon(±)in the App settings screen.

9.7 Holiday Setting

Press the menu button for 5 seconds to open the configuration menu.
• Select holiday mode icon (✈) via the "+/–" button in the menu.
• Confirm with the menu button.
• Select the desired temperature using the "+/–" button and confirm with the menu button. To confirm, the temperature flashes three times.
• Temperature range: 5–30℃, step: 0.5℃.
• Use the boost button to return.
APP operation: Click the holiday mode icon (✈) in the App settings screen.
Note: If there is no operation in the setting interface within one minute, the setting will exit automatically.

10. Set an automation scenarios linkage

If you have a door sensor installed in your home, then you can realize an automation scenarios linkage between TRV and door sensor.
• Under "Automation" in the "Smart" page, click "+" on the upper right corner, you will see a page called Create Smart that will guide you through the setup.
• Here, we take When device status changes setting.
• After you click When device status changes, you will see all the devices you added to the Tuya Smart app.
• Select Smart Door Sensor–>Select Function–>Smart Door Sensor–>ON/OFF–>Set up Task–>Run the device–>TRV–>Open Window Detection–>ON/OFF–> Save–>Next–> Save.
• A prompt box "Automation created successfully" will pop up, select "Yes", you can see all the automation scenarios you've created.
• Now, when the door/window sensor is in the "open" status, the interface will pop up a message that the door/window sensor is turned, and an (🪟) icon will appear on the TRV device interface. When the door/window sensor is closed, the Tuya Smart app interface will pop up a message that the door/window sensor is turned off, and an (🪟) icon will disappear on the TRV device interface.

11. Low Battery

When the battery power is less than 12%, the low power prompt icon (🪫) will be displayed. Please replace the battery as soon as possible. When the screen displays (🪫) the device is not available.

12. Reset

The device operation: Press the "+" and "–" buttons for 5 seconds to enter the reset mode, and the screen will display "FAC".
• Press the boost button to exit.

After the device runs reset, the data will not be saved,the device will automatically connect to the gateway.

13. Troubleshooting and Maintenance

Error code on display	Problem	Solution
Low battery (🪫)	Battery output too low	Replace batteries
F1	Valve drive sluggish	Check installation, check the heating valve
F2	Actuating range too short	Please check the fastening of the thermostat adapter
F3	Adjustment range too small	Re-fit the device in normal position, the valve pin is stuck

14. Technical Data

Model: TV01–BT
Batteries: 2×1.5 V LR6/Mignon/AA
Battery life: 1.5 years
Temperature range: 5–30°C
Degree of protection: ip20
Display: LCD with LED
RF: ZigBee
Frequency: 2.4GHz
Maximum radiated power: 10dBm
Dimensions(H x W x D): 55.3x54x98.3 mm
Weight: 190g(Unit. batteries)
Working temperature: –10°C–40°C
Working environment: Indoor
Safety: CE,ROHS

15. Package contents

ZigBee Radiator Thermostat
AA batteries
Adapters for Danfoss(RA, RAV and RAVL)
Screw for adapter
Operating manual

16. Safety Information

1.Do not disassemble, reassemble, modify, or attempt to repair the product by yourself. If there are any issues, please contact the company's professional maintenance staff.
2.The product's battery should be recycled or disposed of separately from household waste according to local environmental regulations.

17. Storage

Products should be put in the warehouse where the temperature is between the range –10℃ ~ +40℃,and the relative humidity ≤70%RH, Indoor environment with no acid, alkali, salt and corrosive, explosive gas, flammable matter, protected from dust, rain and snow.

18. Control your device by voice

Devices are compatible with Amazon Alexa and Google Home supported functionalities. You can see our step–by–step guide on https://www.moestech.com/blogs/news/smart–device –linked–voice –speaker

19. Declaration of conformity

Hereby,WENZHOU NOVA NEW ENERGY CO.,LTD declares that the radio equipment type TV01–BT is in compliance with Directive 2014/53/EU.2014/30/UE,2011/65/EU. The full text of the EU declaration of conformity is available at the following internet address: https://www.moestech.com/blogs/news/ztrv–zc–tv01

20. WARRANTY INSTRUCTIONS

Dear Sir or Madam, thank you for purchasing the product.
We hope you'll enjoy using it.
Any problems that occur in the warranty card is hereby granted as follows.
As a condition of using the warranty, you must comply with the following terms and procedures.
1. Products are covered by a 24–month warranty, effective from the date of purchase of the warranty period product by an initial customer.
2. In order to exercise warranty rights, the purchaser must present: a) Warranty card, b) Proof of purchase (VAT invoice, financial receipt or other

document confirming the actual date of purchase), unless the purchase date of the product comes from the warranty card.
3. If product quality problems occur within 24 months from the date of receipt, please prepare the product and packaging and go to the place or store where you purchased it to apply for after–sales maintenance. If a product is damaged due to personal reasons, a certain maintenance fee will be charged.
4. We recommend that you properly protect the goods when delivering them to us for repair. We will not be responsible for damage to the original packaging with packing to ensure safe transportation. If you choose to use replacement packaging, we recommend that you ensure that the product is adequately protected from damage during shipping. We recommend that you place an appropriate sticker on your packaging indicating the product is susceptible to impact, such as "Fragile Glass".
5. Reported defects covered by the warranty will be considered
6. Warranty period for the host of the product is the date of delivery of the goods to the Guarantee.
7. After checking and determining the legality of the warranty claim, the Guarantor's services shall be: a) Repair within a reasonable time, not exceeding 30 days from the date of delivery of the goods to the Guarantor; however, if the product cannot be repaired on the deadline may extend the time it takes to deliver the part from the manufacturer's factory.
2. The warranty does not include the performance of maintenance and similar operations specified in the user manual, and users are obliged to do it themselves.
8. If defects occur due to natural wear and tear during use, the warranty does not cover it.
9. The warranty does not cover:
a) Mechanical damage caused by the user's fault and product defects caused by such damage.
b) Damage caused by improper use of the product.
10. The rights of the consumer may be limited in the following circumstances:
a) Remove the warranty seal from the product.
b) Remove the serial number from the product
c) Take out unauthorized mechanical interventions in the product outside of authorized service.
d) Use non–original parts and consumables.

Gebrauchsanweisung (Deutsch)

1.Informationen zu diesem Handbuch

Bitte lesen Sie dieses Handbuch vollständig und sorgfältig durch, bevor Sie das Gerät in Betrieb nehmen. Das Handbuch enthält wichtige Informationen zum bestimmungsgemäßen Gebrauch des Gerätes. Beachten Sie insbesondere die Sicherheitshinweise. Bewahren Sie das Handbuch zum späteren Nachschlagen auf. Wenn Sie das Gerät anderen Personen zur Nutzung überlassen, übergeben Sie bitte auch die Bedienungsanleitung.

2. Produktbeschreibung

Das Gerät bewegt ein Ventil, um den Wärmefluss zum Heizkörper intelligent zu steuern. Mit dem Thermostat–Heizkörperventil TV01 können Sie die Raumtemperatur bequem zwischen 5 und 30 °C regeln und dabei mehr als 15 % Energie sparen. Das Gerät ist Teil des Tuya–Smart–Home–Systems und arbeitet mit dem ZigBee 3.0–Protokoll. Alle Geräte des Systems lassen sich komfortabel und individuell mit der Tuya–Smartphone–App konfigurieren. Die Temperatur kann Raum für Raum individuell regeln. Der Heizkörperthermostat passt auf alle gängigen Heizkörperventile und ist einfach zu montieren – ohne dass Wasser abgelassen oder abgelassen werden muss in die Heizungsanlage eingreifen. Durch die zusätzliche Boost–Funktion kann der Heizkörper kurzzeitig schnell aufgeheizt werden. Vor dem Verlassen des Hauses kann der Ventil auf 5–Maß eingestellt werden. Durch die Strahlungswärme herrscht sofort eine angenehme Raumtemperatur.

3. Geräteübersicht

Die Lebensdauer neuer Alkalibatterien beträgt ca. 1,5 Jahre. Ein Batteriesymbol (🪫) auf dem Display zeigt an, dass die Batterien ausgetauscht werden müssen. Warten Sie nach dem Entfernen der leeren Batterien ca. 1 Minute vor dem Einsetzen der neuen.Dieses Gerät unterstützt keinen Betrieb mit wiederaufladbaren Batterien.

4.3 Datum und Uhrzeit einstellen

Wenden Sie keine Gewalt an, wenn Anzeige oder Ausgabeschalt, erfolgt nach einer kurzen Anzeige der Firmware–Versionsnummer automatisch die Abfrage von Datum und Uhrzeit.
• Stellen Sie Jahr, Monat, Tag, Stunde und Minute mit der +/– Taste ein und bestätigen Sie mit der Menütaste. Sie können die Boost–Taste drücken, um zum vorherigen zurückzukehren
Während der Einstellung von Datum und Uhrzeit gelangen Sie zum nächsten Einstellschritt.
• Die Anzeige von „InS" mit der rotierenden „⏱" zeigt an, dass der Motor noch zurücksteht.
• Wenn im Display „AdA" angezeigt wird, kann der Heizkörperthermostat am Ventil montiert werden. Drücken Sie nach der Installation die Boost–Taste, um Adapter auszuführen.
• Die Anzeige von „AdA" mit der rotierenden „⏱" zeigt an, dass ein Adaptionslauf zur Anpassung des Thermostats an das Ventil.

Die dunkle und die zwei hellen alkalischen Batterien sind nicht länger als 1,5 Jahre. Ein Batteriesymbol (🪫) auf dem Display zeigt an, dass die Batterien ausgetauscht werden müssen. Warten Sie nach dem Entfernen der leeren Batterien ca. 1 Minute vor dem Einsetzen der neuen.Dieses Gerät unterstützt keinen Betrieb mit wiederaufladbaren Batterien.

5. Einbau des Heizkörperthermostats

Der Einbau des Heizkörperthermostats ist einfach und kann ohne Ablassen des Heizungswassers oder Eingriffe in die Heizungsanlage erfolgen. Es sind weder Spezialwerkzeuge erforderlich, noch muss die Heizung ausgeschaltet werden.
Die am Heizkörperthermostat befestigte Ringmutter ist universell und ohne Zubehör für alle Ventile mit dem Gewindemaß M30 x 1,5 der gängigsten Hersteller einsetzbar wie:

Danfoss Heimeier MNG Junkers Landis&Gyr (Duodyr)
Honeywell–Braukmann Oventrop Schlösser Comap
Valf Sanayii Mertik Maxitrol Watts Wingevorth (Winoflex)
Idmar54 R.B.M Tiemme Jaga Siemens

Mittels der im Lieferumfang enthaltenen Adapter kann das Gerät auf Heizkörperventile vom Typ Danfoss RA, Danfoss RAV und Danfoss RAVL montiert werden.

5.1 Schrauben Sie Ihren vorhandenen Heizkörperthermostat ab

Keine Sorge, bei diesem Vorgang tritt kein Wasser aus.

5.2 M30 x 1.5mm

Schrauben Sie den smarten Heizkörperthermostat TV01 direkt an den Heizkörper, wenn der Steckertyp M30 x 1,5 ist (siehe Abbildung unten). Sie können den Winkel anpassen, damit die LED richtig zum Betrachter zeigt.
—Drehen Sie den Thermostatknopf auf den Maximalwert. Der Maximalwert kann 6 oder 8 sein.
—Überprüfen Sie, ob die ⚙ aktiv ist.
—Installieren Sie das Gerät.

5.3 Danfoss RAVL Valve

• Überprüfen Sie, ob die ⚙ aktiv ist.
• Das Ventilgehäuse verfügt über längliche Kerben am Umfang, die sicherstellen, dass der Adapter beim Einrasten richtig sitzt: Lassen Sie den Adapter vollständig einrasten, sodass die Stifte im Inneren des Adapters mit den Kerben am Ventil ausgerichtet sind.
• Installieren Sie den Adapter. Ebene A ist mit Ebene B ausgerichtet.
• Montieren Sie das Rundrohr in das Gerät.
• Installieren Sie das Gerät.

5.4 Danfoss RAV Valve

• Drehen Sie den Thermostatknopf auf den Maximalwert, der Maximalwert kann sein 6 oder 8 sein.
• Überprüfen Sie, ob die ⚙ aktiv ist.
• Das Ventilgehäuse verfügt über längliche Kerben am Umfang, die sicherstellen, dass der Adapter beim Einrasten richtig sitzt: Lassen Sie den Adapter vollständig einrasten, sodass die Stifte im Inneren des Adapters mit den Kerben am Ventil ausgerichtet sind.
• Installieren Sie den Adapter. Ebene A ist mit Ebene B ausgerichtet.
• Montieren Sie das Rundrohr in das Gerät.
• Installieren Sie das Gerät.

5.5 Danfoss RA Valve

• Drehen Sie den Thermostatknopf auf den Maximalwert, der Maximalwert kann sein 6 oder 8 sein.
• Überprüfen Sie, ob die ⚙ aktiv ist.
• Das Ventilgehäuse verfügt über längliche Kerben am Umfang, die sicherstellen, dass der Adapter beim Einrasten richtig sitzt: Lassen Sie den Adapter vollständig einrasten, sodass die Stifte im Inneren des Adapters mit den Kerben am Ventil ausgerichtet sind.
• Installieren Sie den Adapter. Ebene A ist mit Ebene B ausgerichtet.
• Überwurfmutte.
• Montieren Sie das Rundrohr in das Gerät.
• Installieren Sie das Gerät.



6. Schnittstellenanzeige

Wenn Sie sehen, dass die LED die folgenden Informationen anzeigt, ist der Heizkörperthermostat bereit zur Konfiguration. Wenn nicht, deinstallieren Sie bitte die Batterien, setzen Sie sie erneut ein und wiederholen Sie Schritt 4.

7. Vorbereitung für den Einsatz

7.1 Laden Sie die MOES–App herunter

—Laden Sie die Tuya Smart/Smart Life App für Ihr Mobilgerät aus dem App Store oder Google Play.

Die MOES–App wurde um eine viel höhere Kompatibilität als die Tuya Smart/Smart Life App erweitert und eignet sich für die Szenensteuerung durch Siri, Widgets und Szenenempfehlungen sowie der völlig neuen benutzerdefinierten Demo.
(Hinweis: Die Tuya Smart/Smart Life App funktioniert weiterhin, aber die MOES App wird dringend empfohlen.)

Manuale di istruzioni (Italiano)

1.Informazioni su questo manuale

Si prega di leggere questo manuale completo e attentamente prima di iniziare a utilizzare il dispositivo. Il manuale contiene informazioni importanti sull'uso previsto del dispositivo. Osservare specialmente le indicazioni di sicurezza. Conservare il manuale per la successiva consultazione. Se si consegna l'apparecchio ad altre persone per l'uso, consegnare anche le istruzioni per l'uso.

2. Descrizione del prodotto

Il dispositivo muove una valvola per controllare in modo intelligente il flusso di calore al radiatore. Con la Valvola Termostatica per Termosifone TV01 è possibile regolare comodamente la temperatura ambiente tra 5 e 30 °C e risparmiare oltre il 15% di energia. Il dispositivo fa parte del sistema di casa intelligente Tuya e funziona con il protocollo ZigBee 3.0. Tutti i dispositivi del sistema possono essere configurati comodamente e individualmente con l'app per smartphone Tuya. La temperatura può essere controllata individualmente, stanza per stanza. Il termostato per radiatore si adatta a tutti i comuni radiatori ed è facile da montare, senza dover scaricare l'acqua o dover interrompere il riscaldamento. La funzione Boost aggiuntiva consente di riscaldare rapidamente il radiatore per un breve periodo di tempo aprendo la valvola per 4 minuti. Dopo aver caldo irradiato la temperatura ambiente sarà subito gradevole.

3. Descrizione generale del dispositivo

4. Puesta en marcha

4.1 Antes de comenzar

• Se requieren 2 pilas AA para que TV01 funcione, prepárese.
• Se requiere un concentrador de puerta de enlace inteligente para que el TV01 funcione.
• La temperatura se muestra en grados Celsius.

4.2 Insertar (reemplazar) baterías

• Retire la tapa del compartimento de la batería en la parte inferior del dispositivo.
• Inserte 2 baterías LR6 (Mignon/AA) nuevas en el compartimento de baterías asegurándose de que estén en la posición correcta.
• Vuelva a colocar la tapa del compartimento de la batería y asegúrela en su lugar.

La vida útil de las pilas alcalinas nuevas es de aproximadamente 1,5 años. Un símbolo de batería (🪫) en la pantalla indica que es necesario reemplazar las baterías. Después de retirar las pilas agotadas, espere aproximadamente 1 minuto antes de insertar las nuevas. Este dispositivo no admite el funcionamiento con baterías recargables.

4.3 Establecer fecha y hora

Si se insertan o reemplazan baterías, la fecha y la hora se solicitan automáticamente después de una breve visualización