


# Instruction Manua **Series Thermostat**











# Function and display description

- Back home in the evening 5th Period Sleep at night 6th Period


Time period display	Working days (Monday to Friday)		Time period	Hest days (Saturday to Sunday)	
	Time	Temperature	display	Time	Temperature
<b>;</b> ‡•	6:00 Get up	20°C	**************************************	8:00 Get up	20°C
Ωo	8:00 Go to work	16℃			
(A)o	11:30 Noon break	20°C			
(A)	12:30 Go to work	16°C			
∩o.	17:00 Go off work	20°C			
D	22:00 Rest	16℃	O	23:00 Rest	16°C
	display  Cho	Time 6:00 Get up  6:00 Get up  8:00 Ge to work  11:30 Noon break  12:30 Go to work  17:00 Go off work	Time   Temperature	Time   Temperature   Tempera	Time   Temperature   Time   Time

time " I Switch to the next advanced menu parameter, and continue to

# 5. Enable Smart Life Smart Skill then sign in your Smart Life account to









# Bitte scannen Sie den QR-Code, um das deutsche Handbuch, das Installationsvided

# Veuillez scanner le code QR pour obtenir le manuel en français, la vidéo d'installa-

- Technical parameter • Отсканируйте QR-код, чтобы получить руководство на русском языке, видео 1 Model: WHT-S01
- Leia o código QR para obter o manual em português, o vídeo de instalação e a introdução das funções
- Scansionare il codice QR per ottenere il manuale in italiano, il video di installazione e la guida alle funzionalità. Video di installazione e funzionalità
- Zeskanuj kod QR, aby uzyskać instrukcje, filmy instalacyjne i funkcje QR コードをスキャンして、日本語のマニュアル、インストールビデオ、機能紹介を
- λ手してください • QR 코드를 스캔하면 한국어 설명서, 설치 동영상, 기능 가이드 를 볼수 있습니다
- من فضلك قم بمسح رمز الاستجابة السريعه (OR-code), للحصول على دليل المستخدم باللغة العربية وفيديو التثبيت ووصف للوظائف

Parameters

YI ∏ Child lock

dERE Load selection

SLTP Shutdown and annual function activated

RUIT Max . temperature 40°C Adjust range: 30°C-70°C

tion et l'introduction des fonctions

по установке и описание функций

# 明书、安装视频及功能介绍

Functional meaning

Adjust measured temperature range:-9-9°C

ON OF:Turn off the antifreeze function ON:Turn on the antifreeze function ON:Turn on the antifreeze function OF:Close 01:Weekends off 02:Single day off 03:No day off

0: Total darkness 1: 20% 2: 50% 3: Full brightness

1: Low (<1.5KW) 2: Medium (1.5-2.6KW) 3: High (2.6-3.5KW)

Adjust range: 0.5-3°C

### About your thermostats

2.Power supply: 100~250VAC 50/60HZ

5.Temperature display accuracy: ±0.5°C

7.Product size: 86\*86\*38.5MM

9.WiFi frequency: 2.400~2.483GHZ

3.Max. load: 16A (electric heating) /250VAC

4. Working environment temperature: 0°C~50°C

6.Storage environment temperature: -10°C~60°C

8.WiFi communication protocol: IP/TCP, MQTT

10.Maximum Radio Transmit Power: <+20dBm

he device range has been developed to control electric underfloor, water heating or water/ gas boiler systems. These units are designed for use in commercial, industrial, civil and domestic properties

3A (water heating, gas boiler)/250VAC

1. LED display, more friendly interface;

Product introduction

On Appearance

- 2. Touch operation buttons, smoother interaction:
- 3. The ultra-thin embedded panel perfectly fits all kinds of walls:
- 4. The borderless small rounded corner design is simple and atmospheric;
- 5. Compatible with standard 86mm square cassettes and 60mm European cassettes to meet all installation environments;

### On Functionality 1. Rich function options, WIFI, keycard, etc., to meet all your needs;

- 2. Strict temperature control accuracy (±0.5°C) to provide the warmth you
- 3. Power off protection, save all your settings safely; 4. Provide weather information and humidity display
- 5. Support the creation of product local groups/shares to achieve unlimited
- centralized control of the number of products/multi-terminal control:
- 6. Perfect access: Tmall Genie, Amazon echo, Google Home, full experience new voice control method:

### 1. Read these instructions carefully. Failure to follow them could damage the product or cause a hazardous condition.

Before wiring and installing

00000A

Dimension:(mm)

- 2. Check the rathings given in the instructions and on the product to make
- sure the product is suitable for your application. 3. Installer must be a trained, experienced service technician.
- 4. After installation is complete, check out product operation as provided in

# **A** CAUTION

orshort equipment circuitry.

WIRING

Disconnect power supply before installation.

GA is for water heating; GB is for electric heating; GC is for water/gas

boiler;If your boiler has more than three wires, please feel free to contact us

and we will answer the correct installation method for you.NTC is optional.

GA/GC

Electrical Shock or Equipment Damage Hazard. Can shock individuals

INSTALLATION

Your thermostat is suitable for istallation within a standard 86mm pattress box or European 60mm pattress box.

Step 1. Keep power off. See Fig 1.

Step 2. Remove the mounting plate by pushing the LED assembly. See Fig 2.

Step 3. Connect power supply, load into the appropriate terminals.

Step 4. Fix the mounting plate into the wall with screws in the box. See Fig 4.


3.Enter Wi-Fi Password and click "Next", waiting for completing the connec-

tion.Add the device successfully, you can edit the name of the device to enter

(see "Wiring your thermostat" for details and Fig 3).



Icon description



Step 5. Fix the thermostat body and the mounting plate by the lower button.

# U Power on/off button: Short press the power on/off button to turn on/off

Operating instructions

- hour/minute/week, press the plus or minus button to modify the current
- and subtraction keys to adjust the temperature.
- this function Child lock function: When turned on, press and hold the plus and minus

keys for 5 seconds to unlock the child lock. The " 🔓 " icon appears on the screen, and all keys will have no effect. Otherwise, long press the plus and minus keys for 5 seconds to unlock the child lock.

the programming mode, press "  $\blacksquare$  " to switch the hour / minute / temperature

temperature adjustment. The remaining periods are adjusted sequentially according to the above operation.

# of the first period, press "+=" to modify the period of time / minute /

- Back home in the noon 3rd Period Roo out in the noon 4th Period


# In the shutdown state, long press the " \ \mathbb{H} \ " and " = " 5 seconds to enter

the advanced menu settings short press the " \mathbb{H}" to switch advanced menu parameters, press the " 📲 " select the required parameter value, press each return to the first item of the advanced menu setting interface, Press " U " to save to exit the advanced menu settings and return to the shutdown interface

# Parameter default setting

# omplete your account set up.







# categories. Your Smart Life APP has now been paired with Alexa. Now you can control your Smart Device through Alexa.

7. In the Smart Home page, you can group your devices in different



# How to connect Smart Device to Google Home

1). Launch the Google Home App and make sure Google Home speaker is installed. If not, please follow Google Home speaker installation instruction to complete the installation.

2. Open the Google Home app and click on the plus sign in the top left corner to enter the "add and manage" page, then click on "Set up device"

# Low temperature protection function

Home

3. Enter "smart life" in the search box and then search for it. Enable smart

theaccount setup. After successfully logging into youraccount, you need to

Home, and all available smart devices are displayed on the homepage upon

returning. Now you can use Google Home to control your smart devices.

life smart skills, and then log in to your Smart Life account to complete

wait 20 seconds to search fordevices. Once the device is successfully

discovered, it means that your smart life app been paired with Google

When the thermostat is in the shutdown state and the indoor temperature is lower than 5 °C, the thermostat automatically turns on heating (the screen lisplays the " 3" antifreeze icon); When the room temperature rises to 7 °C, ne thermostat automatically turns off the heating (the screen " @ " icon disappears). This feature is only applicable to electric heating.

1.Check the power supply wiring is correct or not.

# Common failure handling

Crash	2.Check the power key
LCD display garbled	The shell is deformed after installation,can be reinstalled.
splay normal No output	Check whether the wiring between the MPU and the power board is damaged.     Check whether the null line of live line is connected wrong.
mperature display error	Adjust the panel temperature display by the first option in the Advanced tab.
Sensor failure	Check the sensor for damage Er1: Built-in sensor disconnected or fault with it. Er2: External sensor disconnected or fault with it.
	Er2: External sensor disconnected or fault with it.

Add and manage

Set up device

+ Add person to home

★ Create new home

☐ Create speaker group

# Add Devices

1.Download Smart Life App





All products marked with the symbol for separate collection of waste electrical

and electronic equipment (WEEE Directive 2012/19 / EU) must be disposed of

health and the environment, this equipment must be disposed

equipment designated by the government or local authorities.

To find out where these collection points are and how they work, contact the

separately from unsorted municipal waste. To protect your

Correct disposal and recycling will help prevent potential

of at designated collection points for electrical and electronic

negative consequences for the environment and human health.





RECYCLING INFORMATION

installer or your local authority.

### - Download "Smart Life" Application - Enter the Register/Login interface;tap

"Register" to create an account by entering your phone number to get verification code and 'Set password". Choose "Log in" if you already have a Smart Life account.

### Method One: 1.Make sure your phone is connected to Wi-Fi and Bluetooth.

Steps for connecting the APP to the device



WARRANTY INSTRUCTIONS

the following terms and procedures:

product comes from the warranty card.

We hope you'll enjoy using it.

Dear Sir or Madam, thank you for purchasing the product.

As a condition of using the warranty, you must comply with

purchase of the covered product by a retail customer.

susceptibility to impact, such as "Warning Glass".



The warranty for the products in the warranty card is hereby granted as follows

1. Products are covered by a 24-month warranty, effective from the date of

2. In order to exercise warranty rights, the purchaser must present: a) Warranty

3. If product quality problems occur within 24 months from the date of receipt.

please prepare the product and packaging and go to the place or store where

damaged due to personal reasons, a certain maintenance fee will be charged.

4. We recommend that you properly protect the goods when delivering them

to the guarantor - for this purpose, we recommend that you use the original

packaging with padding to ensure safe transportation. If you choose to use

replacement packaging, we recommend that you ensure that the product is

place an appropriate sticker on your packaging indicating the product's

adequately protected from damage during shipping. We recommend that you

5. Reported defects covered by the warranty will be considered immediately an

no later than 14 days from the date of delivery of the goods to the Guarantor.

card, b) Proof of purchase (VAT invoice, financial receipt or other document

confirming the actual date of purchase), unless the purchase date of the

you purchased it to apply for after-sales maintenance. If the product is

not cover it.

by such damage.

authorized service.

9. The warranty does not cover:

b) Damage caused by improper use of the product.

a) Remove the warranty seal from the product.

b) Remove the serial number from the product.

d) Use non-original parts and consumables

English

Bluetooth 2. Open the Smart Life App. click the "+" in the upper right corner, enter "Add

2. 46 WiFi connected

1 Make sure your phone is connected to Wi-Fi and Bluetooth



6. After checking and determining the legality of the warranty claim, the

Guarantor's services will repair the product within a reasonable time, not

the time it takes to deliver the part from the manufacturer's factory.

operations specified in the user manual, and users are obliged to do it

exceeding 30 days from the date of delivery of the goods to the Guarantor.

However, if hard-to-find spare parts are required, this deadline may extend

7. The warranty does not include the performance of maintenance and similar

8. If defects occur due to natural wear and tear during use, the warranty does

a) Mechanical damage caused by the user's fault and product defects caused

10. The rights under the guarantee will expire in the following circumstances

c) Take action to eliminate physical defects in the product outside of

the device page by click "Done" .



### In the shutdown state, long press the " = " on the device panel, Until the screen WiFi icon " " is flashing rapidly and the device enters the

How to Reset/Re-pair WiFi Device

Step 6. Installation complete. See Fig 6.

distribution network state. Enter Smart Life Skill in Alexa APP

Complete product networking configuration in the App

Note: In the App, change the name of the device to an easily identifiable name such as Alexa; names are usually in English, such as "bed light".


Complete the device's networking configuration according to the prompts in

### 2. How to connect Smart Device to Amazon Alexa.

device installed like Echo dot, etc.

1. Launch Smart Life App, sign into your account and make sure Smart Device is on the device list 2. Minimize Smart Life App, then launch the Alexa App and sign in your Alexa account and make sure you have at least one Alexa smart speaker-controlled





# Customer Address

r dilaro dato	00000 01 10000	T danc dontone	1



# Maintenance Records

# complete satisfaction, just feel free to share your great shopping experience

# Failure date Cause Of Issue Fault Content Principal

4. Type in "Smart Life "in the search and press the search button next to it.

Thank you for your support and purchase, we are always here for your

WARRANTY CARD

Product Information

Product Name

Product Type\_\_\_

Purchase date\_

Warranty Period

Dealer Information\_

Customer's Name

Customer Phone

# Menu button: In the power on state, press the menu button to switch the

# the device.

### working mode (the screen displays " \" for manual mode and " \" for programming mode): Long press the menu button for 5 seconds to enter the current time adjustment, press the menu button to switch between

### hour/minute/week, press the power button to confirm and exit. # Addition and subtraction button: In the power on state, press the addition

# Energy saving button: In the power on state, press the energy-saving

button to activate the energy-saving function, and press any key to exit

Programmatic mode operation (6 periods of time and temperature) In the shutdown state, press and hold "R" and "P" for 5 seconds to enter















3. In the upper left corner of Home page, press the me button to show APP Menu. Then select 
in the menu.





