











• QR 코드를 스캔하면 한국어 설명서, 설치 동영상, 기능 가이드 를 볼수 있습니다

من فضلك قم بمسح رمز الاستجابة السريعه(QR-code)، للحصول على • دليل المستخدم باللغة العربية وفيديو التثبيت ووصف للوظائف





## **Product Description**

This newly designed wall socket is designed with ZigBee protoc to replace the traditional wall socket. The APP has newly added new pairing mode with Bluetooth enabled, panel indicator mode and relay status setting (power on, power off, power off memory), switch log, child lock, current statistics, overcurrent protection, etc. Enter MOES App, all control modes are effective without any interference. Its design is suitable for different decoration styles, which is really great value for money.

### Warnings

Risk of Electric Shock: Electricity can cause personal injury and property damage if handled improperly. If you are not sure about any part of these instructions, please seek professional assistance from a qualified electrician.

Technical Parameters: Model: ZK-EU(FR/UK) Voltage: 95~245V AC, 50/60Hz Wireless Protocol: ZigBee

# Max. Current(pure resistive load): 16A (UK 13A) Max. Load Power: 3000W Frequency Band: 2.405-2.480GHz Maximum Radio Transmit Power: <+10dBm

Package list: User Manual \*1 Screw bag \*1 Smart Socket \*1

### Warnings:

ver at the circuit breaker and test that power

### Installation

- Wiring.

  Neutral Wire is required.Confirm the wall box contains a Neutral Wire.If the wall box don't have a Neutral Wire.ple try another location at your home or call a professional electrician to install the switch.
- elecurician to install the switch.
   The wire colors indicated in this manual are the usual colors and may differ in some houses.
   Ensure the wire conductors are securely fastened to each wire.
   Ensure the Wi–Fi signal is steady and normally working before wiring and your mobile and Zigbee gataway hub are under the same 2.4GHz WiFi network.
- f you don't have any wiring experience, please call aprofessional

- Turn off the circuit breaker and use the electrical tester to
- test the power.

   Ensure the circuit breaker is off before wiring.



Please disconnect the power supply before installing or removing the device for avoiding irreversible damage on the device from the electric current or some unpredictable problems such as lamp flashing.



### Step 3

Step 2

· Remove the old switch

Remove the switch and pull it away from the wall. Identify Line/Load Wire(Note:The color of your wire may be different from the color shown on the manual.)

mmend you remove the faceplate from the old switch and ctrical tester to test all wires connected to the switch to re is no voltage in the circuit r need to turn off more than one circuit breaker.

Take pictures of the wiring

Follow the wiring diagram to connect the switch wires to the wires in the wall box with the wire conductors

# Step 5


(Please don't install with electricity power on)




### Step 6

### Preparing to install wiring


- A. Connect the live wire to the "L" terminal B. Connect the neutral wire to the "N" terminal C. Connect the ground wire to the "G" terminal
- EU/FR





# Step 7

- Put the switch into switch box in the wall
  Mount the two side screws
  Install the glass panel (install from up above) · Finish installation



### Add Devices

1 Download Smart Life App



### Please scan the QR code or download Smart Life on App store

### 2 Registration or Log in

- Download "Smart Life" Application
- Enter the Register/Login interface;tap "Register" to create an account by entering your phone number to get verification code and "Set password". Choose "Log in" if you already have a Smart Life account.

# 3 Configure the APP to the switch

• Preparation: Ensure the switch has been connected with electricity; ensure your phone has been connected to Wi-Fi and is able to connect to the Internet.

# Note:

The switch only supports 2.4G network. If you have connected 5G network, please disconnect 5G network firstly and connect 2.4G network.

# Steps for connecting the APP to the device


Ensure the device is within the effective signal coverage of your smart ZigBee gateway for successful connection into the WiFi gateway in Smart Life APP

Scan the QR code to configure the network guide 1.Make sure your Smart Life APP has successfully connected to a Zigbee gateway.



(1)

17,0KB/s \$ & 包 2al 2al 余 但D Add Device 圖 日 - VV Power Strip (other) Large Home A Small Home A... Switch IM-F0 Switch (Zigbeel Kitchen Appliances Exercise & Health Switch (BLE) Switch lated Security & Video Su... Gateway Dimme Switch (MI-FI Outdoor Travel (2)



lease connect the device according to the configuration process

0


# Method Two:

1. Make sure your Smart Life APP has successfully connected to a Zigbee gatewa




Press and hold the button for about 7 seconds,un-til the indicator on the switch flash fast after 3seconds. Repair is successful.

3.Enter the gateway.Please follow the picture below to finish as "Add subdevice—LED already blink, and the connecting will take about 10–120 secondsto complete depending on your network condition.



4.Add the device successfully, you can edit the name of the evice to enter the device page by click "Done



5.Click "Done" to enter the device page to enjoy your smart life



# How to Reset/Re-pair ZigBee code

Press and hold the button for about 7 seconds,until the blue indicator on the switch flash fast after 3 seconds. Reset/Re-pair is successful.

# Enter Smart Life Skill in Alexa APP

1. Complete product networking configuration in the App Complete the device's networking configuration according to

the prompts in the App.

Note: In the App, change the name of the device to an easily identifiable name such as Alexa; names are usually in English, such as "bed light".

# 2. Configure the Amazon Echo device

(If you have already configured Amazon Echo, you can skip this step. The following instructions are based on the iOS client.)

① Make sure you Amazon Echo device is powered on and connected to a Wi-Fi network.

(2) Open the Alexa APP on your phone and log in

(3) tap on the menu in the upper left corner of the Home page, select "Settings" and tap "Set Up A New Device" to set up the Amazon Echo. 4 Choose your Amazon Echo device type and language for

connecting.

⑤ Press and hold the small dot on the device until the light turns

© Click "Continue" to connect to the hotspot, connect to the Amazon Echo hotspot, and return to the APP page. 7 Click "Continue" to find and connect to your home Wi-Fi

network

# After the network connection is successful, tap "Continue" An introduction video will appear, After the video ends, tap "Continue" to jump to the Alexa Home page.

1 You have now completed the Amazon Echo's configuration

# 3.Key step —— Link Skill

1 Tap on "Skills" in the Alexa App menu.

2 Then search for "App Name". Tap "Enable" to enable the Skill.

3 Enter the App account and password, then tap "Link Now to link your App account to enable the Skill. Now you can start your smart home journey

### 4.Common commands

Control the device via voice commands, now you can control your smart device with Echo. You can control your device (such as your bedroom light) with the following commands:

- "Alexa, turn on <device name>"
- "Alexa, turn off <device name>

### WARRANTY INSTRUCTIONS

Dear Sir or Madam, thank you for purchasing the product. We hope you'll enjoy using it. The warranty for the products in the warranty card is hereby

granted as follows granted as follows.

As a condition of using the warranty, you must comply with the following terms and procedures:

1. Products are covered by a 24-month warranty, effective from the date of purchase of the covered product by a retail

Customer.

2. In order to exercise warranty rights, the purchaser must present: a) Warranty card, b) Proof of purchase (VAT invoice, financial receipt or other document confirming the actual date of purchase), unless the purchase date of the product comes

rom the warranty card. 3. If product quality problems occur within 24 months from the date of receipt, please prepare the product and packaging and go to the place or store where you purchased it to apply for after-sales maintenance. If the product is damaged due to personal reasons, a certain maintenance fee will be charged. 4. We recommend that you properly protect the goods when

delivering them to the guarantor – for this purpose, we recommend that you use the original packaging with padding to ensure safe transportation. If you choose to use replacement packaging, we recommend that you ensure that the product is adequately protected from damage during shipping. We recommend that you place an appropriate sticker on your packaging indicating the product's susceptibility to impact, such as "Warning Glass".

5. Reported defects covered by the warranty will be

considered immediately and no later than 14 days from the date of delivery of the goods to the Guarantor.

6. After checking and determining the legality of the warranty claim, the Guarantor's services will repair the product within a reasonable time, not exceeding 30 days from the date of delivery of the goods to the Guarantor. However, if hard—to—find spare parts are required, this deadline may extend the time it takes to deliver the part from the manufacturer's factory.

77. The warranty does not include the performance of maintenance and similar operations specified in the user manual, and users are obliged to do it themselves.

8. If defects occur due to natural wear and tear during use,

the warranty does not cover it.

The warranty does not cover:

a) Mechanical damage caused by the user's fault and product defects caused by such damage.

b) Damage caused by improper use of the product. 10. The rights under the guarantee will expire in the following

a) Remove the warranty seal from the product.

b) Remove the warranty sear from the product.
c) Take action to eliminate physical defects in the product outside of authorized service.

d) Use non-original parts and consumables.

# RECYCLING INFORMATION

All products marked with the symbol for separate collection of waste electrical and electronic equipment (WEEE Directive 2012/19 / EU) must be disposed of separately from unsorted municipal waste. To protect your health and the environment, this equipment must be disposed of at designated collection points for electrical and electronic equipment designated by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences for the environment and human health. To find out where these collection points are and how they work, contact the installer or your local authority.









# WARRANTY CARD

Product Information Product Name\_ Product Type Purchase date Warranty Period Dealer Information Customer's Name\_ Customer Phone Customer Address

### Maintenance Records

:	i allule uate	Cause Of Issue	rault Content	Frincipai
l				
1				
:				
I				
ı				

Failure data Causa Of Issue Fault Content Principal